


Moovie

Torre
Tower



Avvertenze // Warning

IMPORTANTE! LEGGERE ATTENTAMENTE E CONSERVARE PER OGNI UTILIZZO FUTURO. WARNING! READ CAREFULLY AND RETAIN FOR FUTURE REFERENCE.

AVVERTENZA! Non lasciare mai il bambino incustodito, anche per brevi periodi.

AVVERTENZA! Non utilizzare il prodotto a meno che tutti i componenti non siano correttamente agganciati e regolati.

AVVERTENZA! Le operazioni di montaggio e di regolazione del prodotto devono essere effettuate da un adulto; non utilizzare il prodotto se il montaggio non è correttamente completato e se il prodotto presenta rotture o pezzi mancanti.

AVVERTENZA! Utilizzare unicamente le parti di ricambio fornite o consigliate dal produttore/distributore.

AVVERTENZA! Non utilizzare accessori non approvati dal costruttore.

AVVERTENZA! Non lasciare che il bambino giochi con questo prodotto. Questo articolo non è un gioco.

AVVERTENZA! Assicurarsi che il prodotto sia completamente eretto prima di posizionarvi il bambino.

AVVERTENZA! Questo prodotto è utilizzabile per bambini che sono in grado di stare in piedi da soli fino a 3 anni di età o peso massimo di 15 kg.

AVVERTENZA! Non collocare il prodotto vicino a fonti di fuoco o altre di calore, come stufe elettriche/stufe a gas/ecc. o ovunque il bambino possa accedere a qualsiasi tipo di pericolo.

AVVERTENZA! Prestare attenzione al rischio di ribaltamento del prodotto nel caso in cui il bambino si spinga dal tavolo o qualsiasi altra struttura.

AVVERTENZA! Non utilizzare il prodotto in vicinanza di scale o gradini.

AVVERTENZA! Utilizzare solo su una superficie piana e stabile.

AVVERTENZA! Non spostare il prodotto con il bambino all'interno.

AVVERTENZA! Pericolo di caduta: non lasciare che il bambino si arrampichi sul prodotto.

AVVERTENZA! Prestare attenzione al rischio generato da fiamme libere e altre fonti di forte calore nelle vicinanze del prodotto.

WARNING! Never leave the child unattended, even for the shortest time.

WARNING! Do not use the product unless all components are correctly fitted and adjusted.

WARNING! The product must be assembled and adjusted by an adult. Do not use the product if it is not properly assembled, if it is broken or if pieces are missing.

WARNING! Only replacement parts supplied or recommended by the manufacturer/distributor shall be used.

WARNING! Do not use accessories which are not approved by the manufacturer.

WARNING! Do not let the child play with this product. This product is not a toy.

WARNING! Ensure your product is fully erected before placing your child.

WARNING! This product is intended for children able to stand on their own unaided and up to 3 years or a maximum weight of 15 kg.

WARNING! Avoid placing the chair near naked heat sources such as electric bar fires, gas fires, etc. or when a child could again access to any others kind of hazard.

WARNING! Be aware of the risk of tilting when your child pushes himself from the table or any other structure.

WARNING! Do not use the product near stairs or steps.

WARNING! Only use on a flat stable surface.









WARNING! Do not move the product with your child inside.

WARNING! Falling hazard: prevent your child from climbing on the product.



WARNING! Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product.






Componenti // Components

A  A1 A2	B  1x	C  1x	D  3x
E  1+1x	F  8x 60 mm	G  6x 40 mm	H  1x

1





Made in Italy by



DELCA srl
Via Sottorive 22
33048 San Giovanni al Natisone
Udine Italy
info@cuoricini.eu
www.cuoricini.eu